


# CD Player, Microphones and hearing aid loop



Microphone ON/OFF switch

If Mic signal green lights do not illuminate when mic is switched on, check batteries in mic.